

BMW

2001-03 530i

PRECAUTIONS

Warning: Batteries produce explosive gases that may cause personal injury. Do not expose the battery to flame or sparks. Always provide adequate ventilation. Do not smoke when working near batteries. Do not place tools or any similar object on the battery.

Warning: Do not allow any battery acid to come into contact with eyes, the skin or clothing. Wear protective clothing, gloves and eye protection. Do not tilt the battery, or acid may leak from the vent hole.

Warning: If acid is splashed into the eyes, rinse them immediately for several minutes with clear water and consult a doctor immediately. Seek medical attention immediately if battery acid is accidentally swallowed. If acid is splashed onto the skin or clothing, neutralize it immediately with a soap solution and rinse with lots of water.

On vehicles with radio code, the radio code must be re-entered after disconnecting the battery. Note stored stations and restore them after connecting the battery. Stored settings of the on-board computer and clock will also be lost. All available central keys must be re-coded for vehicles with first generation infrared transmitter locking systems. DTCs may be set in some control units after battery is connected.

BATTERY

Removal

Disconnect battery ground cable first, followed by battery positive cable. Do not disconnect battery leads while engine is running.

1. Verify that ignition and all other electrical loads are "OFF."



BTY120000000641


Fig. 1 Battery ground cable removal

2. Remove luggage compartment trim on righthand side panel.
3. Loosen locking screw (1), and disconnect battery ground cable, **Fig. 1**.
4. Open cover on positive terminal.
5. Loosen locking screw, and disconnect positive battery cable.
6. Remove mounting screw (1), and remove battery hold down (2), **Fig. 2**.
7. Slide battery to rear and disconnect vent hose.
8. Lift battery from vehicle.

Installation

Connect positive battery cable first, then connect battery ground cable.


1. Position battery in vehicle, and verify that battery is correctly seated.
2. Connect battery vent hose.
3. Install battery hold down bracket (2) and mounting screw (1), then tighten as required, **Fig. 2**.
4. Connect positive battery cable. **Torque** locking screw to 44 inch lbs.
5. Close cover on positive terminal.
6. Connect battery ground cable. **Torque** locking screw (1) to 44 inch lbs, **Fig. 1**.
7. Install luggage compartment trim.



BTY120000000642

Fig. 2 Battery hold down removal

8. Sunroof initialization may need to be performed after battery has been connected. Initialize sunroof as follows:
 - a. Press and hold sunroof switch in "Lift" position. If delayed starting or sudden stopping of sunroof occurs, continue pressing switch in "Lift" position.
 - b. After reaching lift end position (A), keep switch pressed for an additional 20 seconds, **Fig. 3**.
 - c. Normalization is completed when sunroof in lift end position (A) moves briefly in direction of position (B), **Fig. 3**.
 - d. Release switch after normalization for a maximum of five seconds.
 - e. Hold switch in "Lift" position until sunroof has returned to closed position after a complete opening movement.
 - f. Release switch.
 - g. Verify one-touch function, anti-trapping protection and, if required, comfort function.
9. Install a suitably programmed scan tool, and follow manufacturer instructions to clear DTCs that may have been set when battery was disconnected.



BTY120000000643

Fig. 3 Sunroof initialization

The material herein may not be used without the prior express written permission of the copyright holder, including, but not limited to reproduction or transmission in any form by any means such as electronic, mechanical, photocopying, recording or otherwise; nor may it be stored on any retrieval system of any nature.

"The data reported herein has been compiled from authoritative sources. While every effort is made by the analysts to attain accuracy, manufacturing changes as well as typographical errors and omissions may occur on occasion. The publisher cannot be responsible nor does it assume any responsibility whatsoever for such omissions, errors or changes."

MOTOR INFORMATION SYSTEMS
MOTOR is a trademark of Hearst Business Media
A Unit of Hearst Corporation
1301 W. Long Lake, Suite 300
Troy, MI 48098

Copyright © 2012 Hearst Business Media. All rights reserved.
