

VOLVO

2001-04 V70

PRECAUTIONS

Warning: Batteries produce explosive hydrogen gas. Do not allow open flames, burning materials, or sparks near the battery.

Warning: Batteries contain sulfuric acid. Avoid contact with skin, eyes or clothing. Wear safety goggles when working near the battery to protect against possible splashing of the acid solution.

Warning: If acid is swallowed, rinse the mouth with plenty of water and then drink plenty of water or milk. Do not induce vomiting. Seek immediate medical attention.

Warning: When charging the battery, protect face and wear safety goggles. Ensure adequate ventilation.

Warning: In principle, all batteries can cause serious injury if they are short-circuited by, for example, jewelry or metal tools.

Warning: The Supplemental Restraint System (SRS) is active for a certain length of time after the power supply has been disconnected. Wait for a minimum of 3 minutes before disconnecting or removing any SRS components.




Fig. 1 Brace bar removal

Warning: When switching the ignition on for the first time after a battery disconnect and connect, stand outside the vehicle and reach into the vehicle, keeping clear of the air bags operating areas.

Caution: Boost charging with excessive current or voltage above 16 volts will damage the battery.

BATTERY Removal

1. Record radio anti-theft code and station presets.
2. Turn off all lamps and accessories.
3. Turn ignition switch to OFF position.
4. Remove brace bar covers, **Fig. 1**.

5. Remove brace bar, **Fig. 1**.
6. Remove battery cover in direction of arrow, **Fig. 2**.
7. Loosen battery ground terminal clamp, and remove battery ground cable.
8. Loosen battery positive cable clamp, and remove battery positive cable.
9. Remove battery outer cover.
10. Remove battery bracket mounting bolts, **Fig. 3**.
11. Remove battery bracket.
12. Remove battery from vehicle.


Installation

1. Install battery into position.
2. Install bracket, and **torque** mounting bolts to 88 inch lbs., **Fig. 3**.
3. Install battery outer cover.
4. Install battery positive cable, and tighten clamp.
5. Install battery ground cable, and tighten clamp.
6. Install battery cover, **Fig. 2**.
7. Install brace bar, and **torque** bolts to 17 ft. lbs.
8. Install brace bar cover.
9. Reset all preset and theft codes previously recorded to radio.
10. Completely open and close all power windows.
11. Inspect any affected system or component such as clock, comfort adjustment, or compass for proper settings, and adjust as required.



BTY120000000259

Fig. 2 Battery cover removal



BTY120000000260

Fig. 3 Battery removal

The material herein may not be used without the prior express written permission of the copyright holder, including, but not limited to reproduction or transmission in any form by any means such as electronic, mechanical, photocopying, recording or otherwise; nor may it be stored on any retrieval system of any nature.

"The data reported herein has been compiled from authoritative sources. While every effort is made by the analysts to attain accuracy, manufacturing changes as well as typographical errors and omissions may occur on occasion. The publisher cannot be responsible nor does it assume any responsibility whatsoever for such omissions, errors or changes."

"This product contains material that is reproduced and distributed under a license from Land Rover, Volvo, Ford & Jaguar. No further reproduction or distribution of this material is allowed without the express written permission of Land Rover, Volvo, Ford or Jaguar."

MOTOR INFORMATION SYSTEMS
MOTOR is a trademark of Hearst Business Media
A Unit of Hearst Corporation
1301 W. Long Lake, Suite 300
Troy, MI 48098

Copyright © 2012 Hearst Business Media. All rights reserved.
